




CABINET PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2225759	Service & Wiring Sheet
	LIT2225678	Energy Label
	LIT2225411	Use & Care Guide
	LIT2225623	Modular Icemaker Service Sheet
	LIT2225413	Customer Instructions

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	LIT677969	Do-It-Yourself Manual, Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
5	489385	Clamp, Tube (Water Supply Line)
6	3400504	Screw
7	2179826	Rivet
12	549193	Clamp, Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	8281265	Screw
20	2189194	Hinge Butt
21	487576	Washer
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
36		Grille
	2254318	White
	2254321	Biscuit
38	489341	Washer
39	2189356	Clip, Grille
40		Cover, Hinge
	2213360	White
	2213364	Biscuit
41		Rail, Center (Not Serviced)
44	2221775	Cover, Unit
45		Cabinet (Not a Serviceable Part)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET8GHMXLQ01, ET8GHMXT01
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)
	2183948	White
	2205285	Biscuit
5		Handle Center
	2202807W	White
	2202807T	Biscuit
6	489357	Screw
8	8281146	Screw
9		Door Gasket, Magnetic
	2202874	Mist Beige
11	2201051	Trim, Door Shelf
12		Cover, Screw
	2202819W	White
	2202819T	Biscuit
13		Nameplate
	2157907	White
	2213233	Biscuit
14	2195943	Trim, Door Shelf
16	2180027	Trim, Door Shelf
17	8281206	Screw
18	2201052	Trim, Door
19		Freezer Door (Includes #22 & #23)
	2182487	White
	2205279	Biscuit
20		Hole Plug
	2189000	White
	2200936	Biscuit
22	2183003	Thimble
23		Door Gasket, Magnetic
	2214966	Mist Beige
24	2195915	Endcap, Trim
25	2156003	Endcap, Trim
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	2212648	White
	2212649	Biscuit
29	2156007	Plug, Trim
30	2156006	Plug, Trim
31	2205232	Compartment Door
33		Handle, F.C.
	2202806W	White
	2202806T	Biscuit
37	2201050	Trim, Door (2)
41	2156003	Endcap (4)
42	2195949	Trim, Door

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

(White) (Biscuit)

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39

This exploded view diagram illustrates the assembly of a refrigerator. The main components shown include the upper and lower doors (1), the main body (2), the top panel (3), the bottom panel (4), the evaporator fan (5), the condenser fan (6), the compressor (7), the condenser coils (8), the defrost timer (9), the defrost heater (10), the defrost thermostat (11), the defrost switch (12), the defrost relay (13), the defrost control board (14), the defrost control knob (15), the defrost control switch (16), the defrost control button (17), the defrost control lever (18), the defrost control handle (19), the defrost control knob (20), the defrost control switch (21), the defrost control button (22), the defrost control lever (23), the defrost control handle (24), the defrost control knob (25), the defrost control switch (26), the defrost control button (27), the defrost control lever (28), the defrost control handle (29), the defrost control knob (30), the defrost control switch (31), the defrost control button (32), the defrost control lever (33), the defrost control handle (34), the defrost control knob (35), the defrost control switch (36), the defrost control button (37), the defrost control lever (38), and the defrost control handle (39).

5

LINER PARTS


For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2197380	Grommet (2)
3	2254359	Gasket, Evaporator Cover (2)
4	2188376	Defrost Timer
5	2204640	Tube-Barrier, Thermostat
6	941839	Hole Plug
7	2221668	Wire Assy. Control Box
8	2162085	Socket, Light
9	2214976	Bracket Evap. Fan, Rear
10	2214986	Fan Motor
11	2163777	Fan Blade
12	2218381	Control Box
13	2204605	Thermostat Assy.
14	489478	Screw
15	693995	Screw
16	2201170	Cover, Evaporator
17	2160708	Light Bulb
18	98129	Screw
19	1118894	Rocker Arm Switch
21	2176281	Cover, Air Diffuser
22	2202885	Knob, Thermostat
23	2182340	Air Tower
24	2189452	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2179877	Air Diffuser, Top
27	2221677	Defrost Bi-metal
29	2218696	Bracket, Fan Motor
30	2214979	Bracket Evap. Fan, Front
31	2204639	Shield, Heat
37	2171931	Valve, Tube-Body
39	2187686	Wire Assembly, F.C.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2205341	Plate, Unit Mounting	16	489373	Screw			
2	489478	Screw	17	2150304	Roller (2)			
3	2214960	Condenser	18	981126	Rivet			
4	2176300	Heater, Defrost	19	2182338	Clip, Heater			
5	2195391	Evaporator Assy.	21	488500	Screw			
6	489494	Screw	22	531933	Grommet			
7	2172619	Drain Pan	28	2225647	Compressor			
9	2176301	Bracket, Heater			(Includes Items 12, 13, 14 & 29)			
10	2163780	Extension, Air Baffle	29		Drier			
11	2201184	Support Block		2199167	Production			
12		Cover		4387019	Service			
	2162358	Production	30	2155774	Clamp			
	4387731	Service	39	2198921	Air Baffle			
13		Overload	40	2188537	Motor, Condenser			
	2149959	Production	42	2187743	Wire Assy. Unit			
	4387938	Service	43	2190685	Fan Blade			
		(Includes Relay)	44	486692	Nut			
14		Grommet (4)	45	2212603	Tube, Transition			
	1100826	Production	46	2205294	Tube, Discharge			
	4387558	Service	47	2205293	Tube, Suction			
15	2258450	Start Device	48	2212848	Tube, Process			
		Combination	55	3400518	Screw			
		(Start Relay and Overload for Production Compressor Only)	58	2210451	Tray, Evaporator			

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE


4.00 Ozs.
(R134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS


For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
3	488878	Clamp, Tube
4	2181939	Insert, Tube
5	628379	Clip, Fuse
7	2181943	Tube Water
9	489478	Screw, 8 x 1/2
10	2210494	Valve Solenoid
11	627018	Nut Compression
12	2210495	Clip, Water Valve
18	2210484	Cover
19	489464	Screw
20	628228	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Stripper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	627792	Shut Off Arm
32	2187464	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Item 38)
38	489136	Screw, 3-24 x 23/64
39	488208	Screw, 8 x 13/16
40	488886	Screw, 8-18 x 1/2
100	4317943	Complete Icemaker Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET8GHMXLQ01, ET8GHMXL01
(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2200986	Glass, Full Shelf
4	2163835	Track, Crisper
5	489478	Screw
6	2163762	Cup, Shelf Mounting
7	2201107K	Shelf, Cantilever (Includes 8, 13 and 25)
8	2188684	Trim, Shelf Front
9	2200768	Cover, Crisper
11	2221693	Glass, Crisper Cover
13	2188711	Trim, Shelf Side
14	2200985	Glass Shelf
15	2172541	Crisper Support
16	2201109	Shelf Assembly, Cantilever (Includes 3, 13 and 23)
17	2189453	Shelf, Freezer
18	2188688	Trim, Shelf Rear
19	2218140	Pan, Crisper
21	2212446	Body, Humidity Control
22	2176219	Ice Bucket
23	2188690	Trim, Shelf Front
24	2218141	Pan, Crisper
25	2188686	Trim, Shelf Rear
26	2176222	Slide, Humidity Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET8GHMXLQ01, ET8GHMXLT01
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and
Optional Parts (Not Included)

PARTS NOT ILLUSTRATED

978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24" x 48")
876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587	Sealer, Mastic (1 Qt.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1-1/4 Oz.)
606755	Bag, Insulation (36-5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
503695	Cork Sealer (1/4 Pound)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Customer Touch-Up Material

*350942	Primer, White (12 Oz. Spray Can)
*350939	Enamel, Black (12 Oz. Spray Can)
*350930	Enamel, White (12 Oz. Spray Can)
*4392901	Enamel, Biscuit (12 Oz. Spray Can)
72017	Brush Touch-Up Kit (White)
72032	Brush Touch-Up Kit (Black)
4392899	Brush Touch-Up Kit (Biscuit)

Refinishing Material

799344	Enamel, White (1 Qt. Uncut)
4392900	Enamel, Biscuit (1 Qt. Uncut)
833938	Kit, Terminal Connector

***Important:** The spray paint is
not to be used where the paint
may make contact with the door
gaskets.

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ICE MAKER FIELD INSTALLABLE

2155469	ECKMF94
---------	---------

TORX SCREW WRENCH

1117510	Torx Key
---------	----------